Acro Engineering Incorporation



Dimensions: 121(D)x75(W)x110(H) mm

AD1120CF Series

120Watts, Single Output

Features

- High power density
- Universal input range
- · Convection cooled
- RoHS compliance
- 3 year warranty
- Great reliability
- DIN rail / Wall bracket mounting solution
- Over voltage protection
- Overload protection
- Short circuit protection
- Reverse polarity protection

Safety Standards

EMC Standards



EN 60950 (Marking)


EN55011	Class B
EN55022	Class B
EN61000-4-2	Level 3
EN61000-4-3	Level 3
EN61000-4-4	Level 3
EN61000-4-5	Level 3
EN61000-4-6	Level 3
EN61000-4-8	Level 3
EN61000-4-11	Level 3

Model List

Model	Charging Boost	y Voltage Float	Charging Current	Line Reg.	Load Reg.	Efficiency	Over Voltage Protection
AD1120C-12F	14.7VDC	13.8VDC	10.0A Max.	±1%	±1%	80%	18~22VDC
AD1120C-24F	29.4VDC	27.6VDC	5.0A Max.	±1%	±1%	81%	33~37VDC
AD1120C-36F	44.1VDC	41.4VDC	3.3A Max.	±1%	±1%	83%	47~51VDC
AD1120C-48F	58.8VDC	55.2VDC	2.5A Max.	±1%	±1%	83%	63~67VDC

- **NOTE:** 1. Line regulation is measured from low line to high line at rated load.
 - 2. Load regulation is measured from 20% to 100% of rated load at 230VAC input.
 - 3. Efficiency is measured at rated load and 230VAC input.

Model Encoding



Website: http://www.acro-powers.com/ E-mail:service@acro-powers.com.tw Tel:+886-2-22675015 Fax:+886-2-22674939



REV. Apr., 2017 Page 1 of 3

Specification

General		
Switching Frequency		85kHz
	Input-Output	3000VAC /4242VDC
Isolation Voltage	Input-FG	1500VAC/2121VDC
Voitage	Output-FG	500VAC/ 710VDC
Isolation Resi	stance	100MΩ when Input-Output @500VDC
Operating Ten	nperature	-40°C~50°C ambient
Storage Tamp	erature	-40°C to +85°C
Relative Humi	idity	5%~95% RH, Non-condensing.
Temperature	Coefficient	±0.04% of output voltage per °C
MTBF		60,000hrs Min. Per MIL-HDBK-217F, 25°C GB
Attitude Durir	ng Operation	2000m
Installation po	osition	Vertical
Vibration		Random vibration, 10~500Hz. 3 axise
Input		
Input Voltage		100~240VAC/120~370VDC
Input Frequer	ncy	47~63Hz
Inrush Curren	t	22A/115VAC
(cold start)		44A/230VAC
Rated Input C	urrent	2.7A Max., Vi=100~240VAC
Leakage Curre	ent	Input-output 0.25mA, Input-FG 3.5mA
Output		
Line Regulation	on	±1%, measuring from low line to high line rated load
Load Regulati	on	±1%, measuring from 20% to 100% of rated load 230VAC input
Rated Continu	ous Loading	8A@12VDC, 4A@24VDC, 2.5A@36VDC, 2A@48VDC
Turn On Time		1500mS
Efficiency		See model list, measuring at rated load and 230VAC input.
Protectio	n	
Input Fuse		3.15A/250V
Internal Surge	Load Protection	Varistor, IEC6100-4-5
Degree of Pro	tection	IP20
Short Circuit F	Protection	Autorecovery
Over Voltage	Protection	Autorecovery
Rated Over Lo	ad Protection	100%
Overload prot	tection	Power limited


Website: http://www.acro-powers.com/ E-mail:service@acro-powers.com.tw Tel:+886-2-22675015 Fax:+886-2-22674939




REV. Apr., 2017 Page 2 of 3

Charging Curve


Code Type	12V	24V	36V	48V
a (A)	10	5	3.3	2.5
b (A)	0.6	0.6	0.6	0.6
1 (VDC)	14.7	29.6	44.1	58.8
2 (VDC)	13.8	27.6	41.4	55.2




Mechanical Details



Case No.	AD120
Dimensions	121(D)x75(W)x110(H)mm
Case Material	Metal








Terminal Alloc


Designation	Description
DC OK	Green LED Indicator
V Adj.	O/P Voltage adjustment
+	Output Positive
_	Output Negative
Rdy	DC OK signal(Short)
±	Earth
N	Input Neutral
L	Input Line

Installation instruction









Place the top of the AD1120CF rail mount over the top of the DIN rail. Tilt the bottom of the AD1120CF toward the DIN rail until it snaps into place.

To remove the AD1120CF To install AD1120CF on from the DIN rail, use a wall/plate, loosening flathead screwdriver to screws on mounting pull down the bottom of bracket and pull both the rail mount and tilt it brackets out first. Then away from the DIN rail.

re-screwing the two brackets with screws onto wall/plate.

The left housing of AD1120CF is designed as a heat sink, please keeping a minimum distance of 15mm from each other.

Website: http://www.acro-powers.com/ E-mail:service@acro-powers.com.tw Tel:+886-2-22675015 Fax:+886-2-22674939



REV. Apr., 2017 Page 3 of 3